

Installation Instructions

Waterhog Eco Elite

Entry Matting Systems - Classic Series



IMPORTANT - Before proceeding with installation

Inspect the product is as specified and free of any defects or damage. Advance Flooring Systems must be notified immediately if any defect is present. No claims for labour or material will be accepted where defective product has been installed without the prior approval of Advance Flooring Systems Ltd.

Preparation of the subfloors and conditions for use

- The subfloor must be flat, sound, dry and clean in accordance with AS/NZS 2455.1.2007
- The subfloor must guarantee a compressive strength suitable for the traffic and use of the area; if required a levelling compound and a primer should be used.
- Rolls must be opened and loose laid in the area for conditioning min 48 hrs before starting installation; do not to proceed if room temperature is below 18C°.
- Check labels to verify that all rolls are from the same batch and colour complies to the requirements; identify carpet pile and backing before starting installation.
- Claims for colour and appearance will not be accepted on installed material.

Installation

- Unroll the carpet sheets in the same direction, towards the main light source (natural or artificial).
- Rolls must be laid side by side in the same direction and butt joined.
- Avoid cross seams.
- Knee kickers and power stretchers must not be used.
- Fold the carpet sheets back and apply recommended adhesive following adhesive manufacturer's instructions.
- Recommended adhesive tack times must be adhered to.

Installation Instructions

Waterhog Eco Elite

Entry Matting Systems - Classic Series



- Unroll the carpet sheets back in the original position, ensuring that the joint between the sheets is close butted.
- Roll installation immediately to ensure adhesive transfer. Roll from the center out to the edges and joints to ensure no air is trapped under the carpet. Repeat if necessary.
- Wait for min 24 hours before using the area.
- Protect installation from damage.
- Knaplock bars and stair nosings must be used on all unprotected edges.
- For entrance mat installations a matwell frame can be used if required. To avoid trip hazards, we recommend adhering the mat to the subfloor.

Recommended Adhesives

Interior (Dry) and Solvent Free

Uzin2000S

- Extreme care must be taken if using solvents or solvent based adhesive. Solvents can soften and dissolve the carpet backing affecting the performance and service life of the carpet.
- Advance Flooring Systems accepts no liability for failure or damage through incorrect adhesive use.
- Refer to adhesive supplier's data sheets for health and safety instructions which must be followed. Ensure adequate ventilation.

Advance Flooring Systems Ltd
email: info@advanceflooringsystems.com
www.advanceflooringsystems.com

Call us: **0508 238 262**

Advance
FLOORING SYSTEMS